

FIG. 1




Figure 1 is a perspective view of a front-loading washing machine 10. The machine has a main body 11 and a door 11. The door 11 is open, revealing the interior drum 20. The door 11 features a window 14 and a detergent dispenser 13. The control panel 15 is located at the top of the machine. The base of the machine shows the motor 31 and various electrical components labeled 31a, 31b, 35, 51, 52, 53, 54, and 55.




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8

